



**Please see Section 3 of the MC-400 Operations Guide for operating instructions.  
Connection information is on the reverse side.**

# MCP-400 Master Control Panel Connections

