

UDS 10 Front View



Power LED indicates fault with temperature or power supplies

Switch used to reset processing functions or reset to factory settings

UDS 10 Rear View

