UTAH-400 Data Rear View






Serial Data Connector Pinouts **Tributary Mode**

1&2 = gnd, 3 = TX Common, 4 = TX-, 5 = TX+, 6 = RX Common, 7 = RX+, 8 = RX-

Serial Data Connector Pinouts Controller Mode

1&2 = gnd, 3 = RX Common, 4 = RX-, 5 = RX+, 6 = TX Common, 7 = TX+, 8 = TX-



UTAH-400 Data Front View



